

HA0133

DOCKSIDE ROCKER SWITCH CONTROL & 35 FOOT HARNESS



Safety Instructions

- Read and understand this manual before installing this component
- Never exceed recommended lift capacity
- Keep self and others clear of the lift when operating
- Do not allow children to operate lift

Installation Notes

- This switch system can operate a ShoreStation DC (12V or 24V) boat lift. It can be used to replace a pendant or wireless control or it can be installed in addition to an existing wireless or pendant control.
- If this switch is installed in addition to a Wireless system, the top limit connector on this harness should remain connected to the additional connector on the same harness (Marked "DO NOT USE W/WIRELESS").
- If this switch is installed WITHOUT a wireless system, the top limit can be connected to the TOP LIMIT connection on the harness
- The remote switch is designed to be mounted on the dock-side of the lift on the corner post or canopy post using the hose clamp supplied.

- Route the wire harness over the canopy (if installed) using the supplied wire ties. The longer wire ties can be used on the canopy posts. Use a side cutter to trim excess wire ties after installation.
- If a canopy is not installed, the lift should be installed with the lift tube near the dock. Never run the switch harness underwater.

Motor Harness Connection:

