

# ShoreStation Wireless Hydraulic Controller

**WARNING!**

**DO NOT INSTALL OR USE THIS PRODUCT BEFORE YOU FIRST STUDY OWNER'S MANUAL AND UNDERSTAND THE INFORMATION CONTAINED IN IT.**



Locked key fob indicated by 5 flashing lights when a button is press.



Press both the Up and Down buttons for 3 seconds until the mode 1 light flashes. The key fob is now unlocked.



Press and hold the Up button to run the lift up.



Press and hold the Down button to run the lift down.



Press both the Up and Down buttons for 3 seconds until the mode 1 light turns off. The key fob is now locked.